


10117-U TEAK ABSTRACT BLACK RACK ASSEMBLY INSTRUCTIONS FOR ANTI-TIPPING INSTALLATION

HARDWARE ENCLOSED B C (1X) BELT ANTI-TIPPING C (1X) WALL SCREW M4x50mm M4x20mm D E (1X) WASHER WALL PLUG

S8x40mm

TOOLS SCREWDRIVER (not included in package) DRILLING MACHINE (not included in package) (not included in package)



INSTRUCTION

- 1. Install anti-tipping belt (A), washer (D) with M4x20mm screw (C) into the pre-drilled hole on the top back panel of the item.
- 2. Using a 1/4" diameter drill bit, drill the wall at the same level as the anti-tipping belt (A) on the item. Install the wall plug (E) into the hole.
- 3. Connect the anti-tipping belt (A) with wall screw (B) into the wall plug (E)

Ethnicraft

10117-U TEAK ABSTRACT BLACK RACK ASSEMBLY INSTRUCTIONS FOR ADJUSTING LEVELER

